

Replace 2.5L wiring diagram on page 2D-2 of Service Manual 90-849240, and 2.4L wiring diagrams on pages 2D-3 and 8-6 of Service Manual 90-815595, with this updated wiring diagram for engines using electronic throttle position sensor and RPM limiter.

